

Congratulations on the purchase of your Premium Pop-Up Display.

Owner's Manual

Includes: Parts List Assembly Instructions Disassembly Instructions Storage Instructions Care Instructions Warranty Information






Parts List

Important: Before you begin please count and inspect all pieces.


- 2- 12-quad curved frame (A)
- 36- Magnet Bars (B)
- 2- Hardware Bag (C)
- 2- Double LED Light Kit (D)
- 2- Universal LED Light Clip Kit (E)
- 8- Fabric Center Panels (F)
- 3- Fabric End Panels (G)
- 2- Fabric Case-to-Counter Kit (H)
- 2- Oval Shipping Case w/wheels (I)




Assembly Instructions



Step 1 Remove frames (A) from cases. Standing in front or behind expand the frames (A) by pulling up from the middle of the frame.



Step 2 Select the Universal LED Light Clip, item # 150045, (E) and insert into the base of LED Light (D).



Step 3

Plug power cord from the light kit into base of light (D). Then slide light (D) with clip attachment inserted, onto light clip on the top of the frame (A). If you cannot locate the light clips on the frame, check to make sure the frame is not upside down. Repeat for second light and finished expanding frames.


Assembly Instructions (cont.)



Step 4Secure the stability of the unit by engaging the MAGNAFORCE™ locking bars into place.



Step 5Beginning at the bottom and working up, attach the magnet bars (B) by aligning the cut-outs on the bars with the center of the hub on the frame (A). They will snap into place. Apply to the front, and the two back corners.



Step 6Remove panels from protective sleeve. NOTE: Place sleeves in shipping cases. They will be used for storage. Hang the center panels (F) from the hanging pins at top, then attach them to the magnet bars (B) by aligning the magnetic strips. Use one end panels (G) to connect the frames (A) to each other.



Step 7Hang the other two end panels (G). Curl them around the corners and attach them to the magnet bars (B) in front and in back.



Step 8Plug lights (D) into power source and turn the switch on.



Step 9 (Case-to-Counter Kit)Place the wrap part of the case-to-coutner kits (H) around the oval shipping cases (I) and secure with Velcro[®]. Place the oval counter top part of the case-to-counter kits (H) in the groove on top of the shipping cases (I).

Disassembly Instructions



Step 1
Remove all panels and carefully roll them up *fabric/graphic side out* into clear protective sleeves.

Disassembly Instructions (cont.)





Step 2Carefully place rolled panels in shipping cases (H), *fabric/graphic side out*. Roll panels so they are along the perimeter of case.



Step 3Remove all magnet bars (B) from frame (A), and place in hardware bags (C).





Step 4Disengage the locking bars (see Assembly Step 4). Retract the frame half way and remove lights (D) before fully retracting the frames. Leave clip attachement in light, for quick set-up next time. Repack the lights in foam lined carrying cases.



Step 5Fully retract frames and place it, along with the light cases and hardware bags (C), in the open center area inside the shipping casse (I).

Storage Instructions



Store in shipping cases (I), in a cool, dry place.

Care Instructions

Spot clean with damp cloth.

Warranty Information

All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion. Lifetime warranty on frame and hardware.